

Owners Handbook



MADE IN ENGLAND

80

90

120

150

260

500

750

1000

1500

1750



WARRANTY REGISTRATION FORM

Gearbox Model	Engine Make
Gearbox Serial Number	Engine Model
Date of Commissioning	Type of Application (please tick)
Owners/Operators Name	Pleasure <input type="checkbox"/> Commercial <input type="checkbox"/>
& Address	Type of Vessel (please tick)
.....	Canal Craft <input type="checkbox"/> Sailing <input type="checkbox"/> Fishing <input type="checkbox"/>
.....	If Other, please specify:
Country
Telephone Number
Signature	Date

Failure to return this form may invalidate the warranty

PLEASE
AFFIX
POSTAGE
STAMP
HERE

PRM Newage Ltd
Barlow Road
Aldermans Green Industrial Estate
COVENTRY
CV2 2LD
ENGLAND

Contents	Page
Warranty Statement & General Information	2
Installation Advice	3
Nominal Power Ratings	4
Service Classification	5
Oil Type	5
Oil Capacities and Pressures	6
Oil Level Checking	6
Oil Pump Mounting	7
Operation	8
Emergency Operation (not PRM60/90/125)	9-10
Routine Maintenance	11
Optional Equipment	11
Fault Finding Chart	12-13
Distributor Network	14-16
Warranty Registration Card	Inside Front Cover
Maintenance Record	17



Warning: This symbol warns of possible personal injury.



Caution: This symbol warns of any possible damage to transmission.

PRM Newage Ltd operate a policy of product improvement and therefore reserve the right to change specifications without prior notification. Whilst every effort is made to ensure complete accuracy of the information in this manual no liabilities for inaccuracies or the consequences thereof can be accepted by the manufacturer or the distributor/dealer who supplied the manual.

References made to the new models PRM60/90/125 also apply to the older models PRM80 or 120 (apart from power ratings and oil capacities)
References to the new model PRM280D also apply to the old model PRM260D (apart from power ratings, PTO adaption and in-line fitment)

Warranty Statement & General Information

PRM Newage Ltd warrants to Engine manufacturers and to PRM Newage Ltd distributors that all PRM marine gearboxes manufactured by PRM Newage Ltd will be free from defects in material and workmanship under normal use and service for the period as follows,

Twenty four months from date of despatch from PRM Newage Ltd.

It is essential that all PRM hydraulic and mechanical marine gearboxes are correctly installed, aligned and maintained.

This handbook contains important instructions to ensure this and it is of the utmost importance that these are carefully followed. PRM Newage Ltd can accept no responsibility under warranty or otherwise for any loss or damage resulting from failure to observe these instructions.

To avoid prejudicing warranty rights, do not undertake any repair or other work on the gearbox during the warranty period without first contacting PRM Newage Ltd or an authorised distributor or dealer for advice. In the event of failure, this should be done via the local PRM Newage Ltd distributor/dealer or PRM Newage Ltd direct.

This warranty does not apply to any gearbox or part that has been subject to misuse, negligence, damage, improper maintenance, incorrect storage or use beyond rated capacity.

Serial Number Plate (Note it is important that this serial number is submitted with any warranty query)

On the top half of the gearcase of every PRM Newage Ltd gearbox is an identification plate with two lines of numbers. The top line is the gearbox serial number, whilst the lower line comprises the gearbox specification (model, ratio, etc.).

Pre Delivery Test

Before leaving the factory each gearbox is subject to a final test and inspection, which includes the following:

1. Flush clean
2. Check time to reach operating temperature
3. Pressurise case, check for leaks
4. Check noise level
5. Check drag in neutral
6. Check valve block operating force
7. Check operating temperature
8. Check operating oil pressure (Not PRM60/90/125)
9. Check output nut torque
10. Check input spline dimensions
11. Check bolt torques
12. Check coupling concentricity

Note: Throughout this owners' handbook, engine and propeller rotations are always described as seen looking forward from propeller to gearbox.

INTRODUCTION

PRM Newage Ltd marine gearboxes are purpose designed and built for smooth, reliable and efficient operation. This handbook contains important information on the installation, operation and maintenance of your gearbox. **It is essential that all owners acquaint themselves thoroughly with their gearbox and follow carefully the instructions contained in this handbook.**

Important

In order to avoid possible danger to persons or property due to accidents arising from mis-use of the gearbox it is essential that the gearbox be used in conformity with the technical information provided by PRM Newage Ltd and that the owner/operator carefully follows the installation, operation and maintenance instructions provided to ensure that operation is as safe as possible. All working machinery must be regularly checked and inspected to ensure this.

Installation Advice

Engine/Gearbox Drive

Drive is transmitted to the gearbox via a flexible input coupling mounted on the engine flywheel, into the centre of which the gearbox input shaft locates. It is most vital that the engine, gearbox and coupling are correctly aligned; if not, vibration, transmission noise and even failure may result. For complete alignment instructions refer to the gearbox workshop manual.

Oil Cooler

All PRM Newage Ltd gearboxes (except PRM60/90/125) must be fitted with an oil cooler to maintain correct working temperatures. Two 3/8 in. BSP (1/4 in. BSP on PRM150, 1/2 in. BSP on PRM1500) connections are provided on the valve block to allow a suitable cooler to be fitted; these are blanked off with “Redcap” plugs for delivery from the factory. The gearbox oil cooler is usually mounted on the gearbox adaptor flange or the bulkhead of the boat and then connected into the engine cooling system. Full instructions on cooler installation are provided in the workshop manual. See caution note reference cooler pressures page 7.

Input Rotation

In their standard form, PRM Newage Ltd marine gearboxes are built for use with left hand (anti-clockwise) rotating engines, at the ratings listed on page 4. The majority can, however, easily be adapted right-hand (clockwise) rotating engines, simply by turning the oil pump through 180°.

(Note: this does not apply to the PRM60/90/125/150/1500/1750 gearboxes, which must be used with left-hand rotating engines only.)

Propeller Shaft Alignment

Correct alignment of the propeller shaft coupling flange and the gearbox output flange is essential, since misalignment can cause excessive vibration and stress, leading to damage and possible oil seal and bearing failure.

Alignment should only be carried out with the boat afloat, the maximum permissible misalignment being 0.05mm; see workshop manual for instructions.

Installation Angle

The transmission should normally be installed so that the maximum fore and aft angle relative to the waterline does not exceed 17° (15° on PRM60/90/125/150) with the vessel at rest. If installation angles greater than this are required, please consult PRM Newage Ltd for advice.

Twin Installations (Not PRM60/90/125)

For efficient operation, it is usually considered preferable for the starboard (right hand) propeller to rotate clockwise and the port (left hand) propeller to rotate anti-clockwise.

Remote Control Operating System

It is strongly recommended that PRM Newage Ltd gearboxes are used with a remote control operating system, **which should be connected strictly in accordance with the manufacturers' recommendations.** Care must be taken to ensure that the cable moves the gearbox operating lever approximately 2mm short of its forward or backward travel, to prevent the lever being brought 'hard-up' against its end stop with every gear shift. This does not apply to PRM60/90/125 which must be adjusted against the stop in both directions. Failure to correctly adjust the shift lever may result in premature wear to the drivetrain and gearbox failure. PRM Newage Ltd gearboxes are provided with a positive neutral position, which greatly assists in setting up the remote control operating system.

Nominal Power Ratings - PRM Mechanical/Hydraulic Reserving Marine Gearboxes												
Model	Shaft Arrangement	Ratio	Input Rotation	Output Rotation	Maximum Input Speed Rev/Min		Nominal Power Ratings per 100 rev/min					
							Pleasure		Light Commercial		Heavy Commercial	
					Continuous	Intermittent	kW	BHP	kW	BHP	kW	BHP
PRM60D	Offset Only	1.52:1	LH	RH	4500	-	0.73	0.98	0.60	0.80	-	-
		2.00:1	LH	RH	4500	-	0.63	0.85	0.51	0.68	-	-
		2.50:1	LH	RH	4500	-	0.63	0.85	0.43	0.58	-	-
PRM90D	Offset Only	2.04:1	LH	RH	5000	-	0.94	1.26	0.62	0.83	-	-
		2.50:1	LH	RH	5000	-	0.82	1.10	0.54	0.73	-	-
PRM125D	Offset Only	2.04:1	LH	RH	5000	-	1.31	1.75	0.71	0.95	-	-
		2.50:1	LH	RH	5000	-	1.04	1.39	0.71	0.95	-	-
		2.94:1	LH	RH	5000	-	0.86	1.15	0.60	0.80	-	-
PRM150D	Offset Only	1.53:1/2.09:1/2.82:1	LH	LH/RH	4500	5000	1.57	2.10	1.12	1.50	-	-
PRM260C	In-Line	1.96:1/2.94:1	LH/RH	LH/RH	4000	4500	2.72	3.65	2.51	3.36	2.31	3.08
PRM280D	Offset Only	1.96:1/2.94:1	LH/RH	LH/RH	4000	4500	2.93	3.93	2.83	3.79	2.67	3.58
PRM500D	Offset Only	1.46:1/1.94:1	LH/RH	LH/RH	4000	4500	4.76	6.38	4.62	6.19	4.40	5.90
		2.57:1/2.90:1	LH/RH	LH/RH	4000	4500	4.62	6.19	4.40	5.90	4.40	5.90
PRM750A	8° Down Angle	1.09:1/1.46:1	LH/RH	LH/RH	4000	4500	7.17	9.62	5.68	7.62	5.39	7.23
		1.94:1/2.57:1	LH/RH	LH/RH	4000	4500	7.07	9.48	5.68	7.62	5.39	7.23
		2.90:1	LH/RH	LH/RH	4000	4500	5.96	8.00	5.60	7.51	5.24	7.02
PRM750D/C	Offset & In-Line (4:1 In-Line Not Available)	1:09/1.46:1	LH/RH	LH/RH	4000	4500	7.85	10.52	6.07	8.13	5.86	7.85
		1.94:1/2.57:1	LH/RH	LH/RH	4000	4500	7.07	9.48	5.86	7.85	5.55	7.43
		2.90:1/3.95:1	LH/RH	LH/RH	4000	4500	5.96	8.00	5.60	7.50	5.24	7.02
PRM1000D	Offset Only	1.53:1	LH/RH	LH/RH	3000	3500	10.47	14.04	7.75	10.39	7.33	9.82
		2.03:1	LH/RH	LH/RH	3000	3500	9.43	12.64	7.44	9.96	7.02	9.40
		2.86:1/4.00:1	LH/RH	LH/RH	3000	3500	8.58	11.50	7.44	9.96	7.02	9.40
PRM1000A	10° Down Angle Only	1.53:1	LH/RH	LH/RH	3000	3500	9.66	12.95	7.10	9.52	6.67	8.95
		2.03:1	LH/RH	LH/RH	3000	3500	9.43	12.64	7.10	9.52	6.67	8.95
		2.86:1	LH/RH	LH/RH	3000	3500	8.58	11.50	7.10	9.52	6.67	8.95
PRM1500D	Offset Only	3.12:1/3.88:1/4.50:1	LH	LH/RH	2500	3000	15.70	21.06	14.65	19.65	13.63	18.28
		4.90:1	LH	LH/RH	2500	3000	13.63	18.28	12.58	16.87	11.53	15.46
PRM1500S	Offset Only	1.22:1/1.56:1/1.94:1	LH	LH/RH	2500	3000	15.70	21.06	14.65	19.65	13.63	18.28
		2.25:1/2.45:1	LH	LH/RH	2500	3000	15.70	21.06	14.65	19.65	13.63	18.28
		3.00:1	LH	LH/RH	2500	3000	14.12	18.93	13.07	17.52	11.76	15.77
PRM1750D	Offset Only	3.12:1/3.88:1/4.50:1	LH	LH/RH	2500	3000	18.33	24.58	17.04	22.85	15.76	21.13
		4.90:1	LH	LH/RH	2500	3000	16.76	22.48	15.58	20.89	14.41	19.32
PRM1750S	Offset Only	1.22:1/1.56:1/1.94:1 2.25:1/2.45:1/3.00:1	LH	LH/RH	2500	3000	18.33	24.58	17.04	22.85	15.76	21.13

Note:- PRM60D Astern ratio 2.05:1 max power rating in reverse de-rated by 40% of listed rating
PRM90D Astern ratio 2.5:1 max power rating in reverse de-rated by 50% of listed rating
PRM125D Astern ratio 2.5:1 max power rating in reverse de-rated by 30% of listed rating

Note: These powers are expressed in BHP and KW per 100 rev/min engine operating speed and are measured at the engine flywheel. Ratings have been established to ensure the long and trouble free life of the gearbox which should not therefore, be used at powers in excess of those shown. PRM Newage Ltd accepts no liability, whether under warranty or otherwise, in respect of transmissions which have been used at ratings higher than those listed above.

Service Classification

Pleasure: limited to planing hull pleasure craft with a maximum of 500 hours operating time per year, of which not more than 5% should be at full engine throttle, with the balance of usage at 90% or less of full throttle. The use of PRM marine gearboxes according to this classification in any commercial boat, or in sport-fishing charter boats or long-range pleasure cruisers, is not approved.

Light Commercial: planing or semi-displacement craft used in pleasure or commercial application may qualify for light commercial rating if annual usage is less than 1500 hours and full throttle operation is limited, with most operating time at partial throttle.

Heavy Commercial: all displacement and semi-displacement craft used for commercial applications should be classed as heavy commercial duty. In this type of vessel (such as trawlers, purse seiners, lobster and crab boats, tugs, ferries, offshore supply boats etc.) the gearbox is expected to work at full governed engine speed. The power setting of the engine must be known and must be within the permitted heavy commercial rating of the gearbox.

Important Note

1. It is essential that the engine, transmission model, reduction ratio and propeller size are correctly matched so that the engine can attain its rated speed appropriate to the relevant service classification without labouring.
2. It is also necessary to ensure the torsional compatibility of the complete propulsion system from engine through to propeller, since disregarding this may result in gear noise, particularly at low speed operation and may even result in damage to the engine as well as to transmission components.

PRM Newage Ltd will provide all possible information and assistance to help find solutions to potential torsional problems, but it is the ultimate responsibility of the person assembling the drive and driven equipment to ensure that they are torsionally compatible.

Oil Type

Hydraulic Gearboxes

PRM 150 / 260C / 280 / 500 / 750 / 1000 / 1500 / 1750	
Temperature	Type of Oil
Below Zero	10W30 or 20W Mineral Engine Oil.
0°C to 30°C	10W30 or 15W40 Mineral Engine Oil.
Above 30°C	10W30 or 40W Mineral Engine Oil.

Mechanical Gearboxes

PRM 60 / 90 / 125 – ATF Dextron II or III
--

Failure to comply with the above oil types or to seek advice from PRM Newage Ltd for approval for any type of oil not listed may result in forfeiture of warranty cover since no claims under warranty will be entertained if oil of the wrong type is used.

Oil Capacities and Pressures

Model	Approximate Oil Capacity		Operating Pressures			
			Minimum		Maximum	
	Litres	Pints	bar	lb/in ²	bar	lb/in ²
PRM60	0.2	0.35	-	-	-	-
PRM90	0.3	0.53	-	-	-	-
PRM125	0.4	0.70	-	-	-	-
PRM150D	1.4	2.50	25.51	370	28.96	420
PRM260C	1.4	2.50	18.27	265	22.06	320
PRM280D	1.5	2.64	20.00	290	22.06	320
PRM500D	2.5	4.40	18.27	265	22.06	320
PRM750D	2.5	4.40	30.34	440	33.44	485
PRM750D4	3.5	6.16	30.34	440	33.44	485
PRM750A	3.0	5.28	30.34	440	33.44	485
PRM750C	3.0	5.28	30.34	440	33.44	485
PRM1000D	3.0	5.28	30.34	440	33.44	485
PRM1000D4	4.0	7.04	30.34	440	33.44	485
PRM1000A	3.5	6.16	30.34	440	33.44	485
PRM1500D	10.0	17.60	28.27	410	31.03	450
PRM1500S	8.0	14.00	28.27	410	31.03	450
PRM1750D	10.0	17.60	28.27	410	31.03	450
PRM1750S	8.0	14.00	28.27	410	31.03	450

The pressures listed above assume a gearbox operating temperature of 70°C and an input speed of no less than 1500 rev/min. Pressure gauge reading 600PSI maximum can be connected to the 1/8" BSP pressure port on the valve block (see opposite illustration).

Oil Level Checking

The oil capacities listed are approximate since they do not include the amount needed to fill the cooling circuit (not PRM60/90/125), which therefore has to be added to give the total volume of oil required for the total gearbox system.

In any event the above table is provided for guidance only and care must be taken to ensure that the gearbox is topped up to the maximum level on the dipstick.

NOTE:- Never overfill mechanical gearboxes !!!!!

The correct way of checking the oil level by using the dipstick is:

1. First fill the gearbox with the correct quantity and specification of oil (see above and page 5).
(for PRM 60/90/125 there is an oil level plug on the left hand side which should be used to ensure the gearbox is not overfilled)
2. Ensure that the gearbox is in neutral.
3. Run the engine and gearbox to ensure that there is oil in the cooling circuit.
4. Switch off, then remove and wipe the dipstick.
5. **Screw the dipstick fully down**, then remove it and read the oil level.
6. Top up with the approved oil (see page 5) to the maximum mark on the dipstick.
7. Replace the dipstick, **ensuring that it is fully screwed down.**



WARNING: Do not remove dipstick with engine running. HOT OIL CAN CAUSE BURNS.



CAUTION: Clean area around dipstick prior to filling with oil or checking level.

Note: using the gearbox with insufficient oil is likely to lead to low oil pressure, unsatisfactory operation, overheating and eventual failure. Equally, filling the gearbox with too much oil may cause overheating and oil leaks; **it is the owner/operators responsibility, therefore, to ensure that the oil level is correct at all times.**

Dipstick Location

PRM60/90/125 Hand screw in dipstick on top of gearcase; **PRM150** 18mm A/F hex plug, rear of case, L/H side; **PRM260C/280/500/750** 18mm A/F hex plug, front of case, R/H side; **PRM1000** 18mm A/F hex plug, front of case, L/H side; **PRM1500/1750** 18mm A/F hex plug, R/H side mounting pad.



Caution: If the operating pressure is below the minimum value listed for your specific gearbox model, corrective action must be taken (see fault-finding chart) or gearbox damage may result. (Not applicable to PRM60/90/125.)

If operating pressure is higher than the maximum listed, (other than for very short periods after start-up when the oil is still cold), qualified assistance must be sought to correct the condition. (Not applicable to PRM60/90/125.)




Caution: It is important to ensure that any oil cooler used is capable of withstanding lubrication pressures in the order of 20.7 bar (300lb/in²). This may be seen on initial start-up from cold at maximum engine speed.

Oil Pump Mounting

The mounting positions of the oil pump are as follows:-

(Not applicable to PRM60/90/125/150/1500 &1750)



Note: Engine rotation is described as seen looking on the flywheel from behind the engine.

Output Rotation (does not apply to PRM60/90/125)

Because PRM Newage Ltd gearboxes have identical clutches, gears and bearings on both input shaft and layshaft, either a L.H. or R.H. propeller can be used at their full speed and horse power ratings, irrespective of input rotation (see rating chart). (PRM150/1500/1750: L.H. input rotation only.)

On all offset gearboxes (except PRM150) used with the more common left-hand (anti-clockwise) rotating engines, moving the gearbox operating lever back provides right-hand propeller rotation and moving it forward provides left-hand propeller rotation.

If the gearbox is used with the less common right-hand (clockwise) rotating engines, the operation is reversed:- moving the gearbox operating lever back provides left-hand propeller rotation and moving it forward gives right-hand propeller rotation. On angle drive (PRM750A, PRM1000A) and inline (PRM260C, PRM750C) gearboxes, the movement of the operating lever is the reverse of that described above.


On PRM150 only moving the gearbox operating lever to port provides right-hand propeller rotation and moving it to starboard provides left-hand propeller rotation.

Important: right-hand propeller required for PRM60/90/125

Note: engine and propeller rotations are described as seen looking forward from propeller to gearbox. In order to achieve the best possible gear shifting, it is recommended that a single lever control system (i.e. connected to the engine throttle as well as the gearbox should be used)

Operation

Ensure the cable that operates the selector lever allows the lever to travel fully up to the stops in the forward and reverse positions at all times.



First Time Usage

Before starting the engine remove the dipstick, fill the gearbox with one of the recommended lubricants (see table on page 6) to the maximum mark on the dipstick, then replace the dipstick by screwing it fully down for correct level.

Ensure that the gearbox is in neutral (we recommend that the optional neutral safety start switch (not available on PRM60/90/125) be wired into the starter circuit to avoid uncontrolled boat movement on start-up), then start the engine and run for a few minutes to allow the oil to circulate through the cooling circuit. Stop the engine, let the oil settle, then re-check the level and 'top up' to the maximum mark on the dipstick (see page 5).

Operating Temperature

Normal operating temperature should be between 50°C - 80°C with a maximum of 90°C permissible for very short periods only. If the gearbox consistently runs at temperatures above 80°C, carry out the checks listed in the fault-finding chart; if no fault is found, fit a larger capacity cooler.

Gear Shifting (Except PRM60/90/125)

PRM Newage Ltd hydraulic marine gearboxes have been designed and tested to ensure rapid shifts from ahead to astern and vice versa at full horsepower ratings and speeds if necessary. However, since full-power shifts do place abnormal, even if short lived, loads on the gearbox and if used indiscriminately as it will reduce the operating life, they should be reserved for emergency use only.

Gear Shifting PRM60/90/125 Only

Caution: Engine must be at idle before changing direction. Pause in neutral when selecting ahead or astern. The PRM60/90/125 can be used with remote control operating systems which must be of the single lever type of remote control, i.e. Morse MT3 or SL3 which controls both the engine throttle and gear selection.

Trailing (Free-wheeling) the Propeller

The bearings used in PRM Newage Ltd gearboxes have been carefully selected to ensure that prolonged trailing (free-wheeling) of the propeller will not harm the transmission. This allows the propeller to turn freely with the engine shut down, making the gearbox particularly well suited for use in auxiliary sailboats, motor sailers, or multi-engine installations where the boat may be operated with one or more engines shut down.

Emergency Operation (Except PRM60/90/125)

Included as standard in every PRM Newage Ltd hydraulic marine gearbox is a "get-you-home" device which, in the unlikely event of hydraulic failure, enables the gearbox to be locked in 'ahead' allowing the boat to be brought to safety.



Warning: To operate, first switch off the engine, disconnect the operating cable and ensure that the gearbox operating lever is in the neutral position, then proceed as follows:

a) PRM150

- 1) Remove the 9 hexagonal bolts securing the rear manifold to the gearcase and taking care not to lose the small socket wrench located inside it, take off the manifold complete with oil pump.
- 2) Rotate the input shaft until two socket screws in the clutch align with the two holes in the rear of the gearcase.
- 3) Insert the socket wrench through the two holes and tighten each screw in turn; this locks up the clutch plates, providing drive for a right-hand rotating propeller. (Note: left-hand rotation cannot be provided).
- 4) Refit the rear manifold and tighten the bolts to a torque of 30Nm.
- 5) Ensure that sufficient oil remains in the gearbox to avoid further damage.

b) PRM260C and PRM280D

- 1) Remove the top cover (located alongside the valve block).
- 2) Select the shaft which provides the appropriate propeller rotation (see note 'a' on page 10) and rotate until one of the grooves on the outer edges of the clutch end plate is uppermost.
- 3) Take one of the top cover securing screws and screw it tightly into the threaded hole in the clutch plate directly beneath the groove: this clamps the clutch and provides drive.
- 4) Check that the dipstick does not foul the head of the screw now fitted in the clutch: if it does, remove the dipstick and plug the hole with a clean cloth.
- 5) Ensure that sufficient oil remains in the gearbox to avoid further damage and refit the top cover, tightening the bolts to a torque of 28Nm.

c) PRM500 and PRM750

- 1) Remove the top cover (located alongside the valve block).
- 2) Select the shaft to provide the required propeller rotation (see note 'a' on page 10) and rotate until the spring slip, which holds the two clamping screws in position, is accessible.
- 3) Remove the spring clip and tighten the two screws: this locks up the clutch pack and provides the drive.
- 4) Check that the dipstick does not foul the head of either clamping screw; if it does, remove the dipstick and plug the hole with a clean cloth.
- 5) Ensure that sufficient oil remains in the gearbox to avoid further damage and refit the top cover, tightening the bolts to a torque of 28Nm.

d) PRM1000

- 1) Remove the top cover (located alongside the valve block): the hexagonal key for operating the emergency device is held in a clip on the underside of this cover.
- 2) Select the shaft to provide the required propeller rotation (see note 'a' on page 10).
- 3) Locate the clutch end plate: this has three tapped holes, angled to provide access. Rotate the shaft until one of the holes is uppermost.
- 4) Insert the hexagonal key and screw the grub screw as tight as possible, rotating the clutch gear to ensure the screw locates in between the spline teeth.
- 5) Rotate the shaft and similarly tighten the other two grub screws.
- 6) Ensure that sufficient oil remains in the gearbox to avoid further damage and refit the top cover, tightening the bolts to a torque of 28Nm.

e) PRM1500/1750

- 1) Remove the oil pump, held on by 6 hexagonal bolts.
- 2) Remove shimming and bearing cup.
- 3) Rotate the input shaft by using the pump slot to expose 4 socket headed grub screws. These need to be tightened with a 4mm hexagon key to engage the clutch.
- 4) Repeat above operation by removing the cover, if appropriate clutch is used for ahead. This is located next to the oil pump.
- 5) Replace bearing cup and shimming.
- 6) Re-seal the oil pump back into place and fix on with the six bolts.
- 7) Ensure that sufficient oil remains in the gearbox to avoid further damage.

The engine can now be run, but to minimise the possibility of further damage being caused to the gearbox, engine speed should be limited to 1/3 full throttle.

Important Notes

- a) Assuming an anti-clockwise engine, the shaft to select is:
- Left-hand propeller: left-hand shaft (PRM280C, 500D, 750D, 1000D, 1500S/D, 1750S/D)
right-hand shaft (PRM260C, 750A, 750C, 1000A)
 - Right-hand propeller: right-hand shaft (PRM280C, 500D, 750D, 1000D, 1500S/D, 1750S/D)
left-hand shaft (PRM260C, 750A, 750C, 1000A)

(all rotations are described as seen looking forward from the propeller to the gearbox).

(only right-hand propeller rotation can be provided by the PRM150 emergency device).

-  b) Caution: When emergency drive is engaged, neither astern or neutral can be used and there is thus no means of stopping the boat using the gearbox; consequently great care must be taken when manoeuvring the boat, particularly during docking.

- c) After emergency drive has been used, qualified assistance must be sought to check the transmission thoroughly before it is used again.
- d) Never use the top cover for topping up the oil.

Routine Maintenance

It is recommended that all PRM Newage Ltd gearboxes be run for 15 minutes before the oil is drained and replaced.

After the first 25 hours of running

Run the engine until the oil reaches a minimum temperature of 50°C, then switch off, drain the oil from the gearbox and cooling system and re-fill with one of the recommended lubricants. Operate the engine and gearbox, allowing the oil to circulate, then stop the engine and let the oil settle. Re-check the oil level by screwing the dipstick down fully and top up if necessary to the maximum mark on the dipstick.

Note: Drain plug located rear right-hand side on PRM1500/1750, 1000, 750 and 150, front on 260C, 280D and 500D and on the side of the main case under the selector lever of PRM60/90/125.



Warning: Hot oil burns

Daily

Check the oil level and check visually for oil leaks, especially around the output shaft oil seal and at gasket sealing surfaces.

Annually

Check oil cooler hoses and connections and correct/replace as necessary. Check propeller shaft alignment and correct if necessary. Ensure that the remote control operating linkage is adjusted to give the correct travel on the gearbox operating lever (see page 3). Check that all fasteners are tightened to the correct torque (see workshop manual for this information).

Oil Changes

Gearbox oil should routinely be changed annually or at intervals corresponding with engine oil changes, whichever occurs first. However, if the oil should become contaminated by water, or if the gearbox suffers major mechanical damage, the gearbox, oil cooler and hoses must be thoroughly flushed out and the gearbox re-filled with fresh oil to the correct specification.



Warning: Hot oil burns

Optional Equipment

Neutral Safety Switch (Not available for PRM60/90/125)

This switch ensures the engine cannot be started unless the gearbox is in neutral; PRM Newage Ltd strongly recommends that it should be fitted in all installations. The device is standard supply on the PRM1000.

Power Take Off – PRM280/500/750/1000/1500/1750

The power take off mounts directly to the rear face of the gearbox and is available factory fitted or as an assembly for retro-fitting on existing gearbox installations. It is designed for use with hydraulic pumps to SAE J744C series “B” specification and is a very compact, economical and effective method of powering hydraulic equipment on vessels where the provision of an auxiliary drive from the main engine may be difficult or expensive.

Whilst gear, vane or piston hydraulic pumps can be used with these units, they must not be fitted with any adaption for driving an outrigger pulley since the mounting provided is not designed to handle the side loads which this would entail.

The clutched PTO unit available on the PRM1000 provides pump rotation in the same direction as the engine, whereas the clutched PTO for the PRM1500/1750 and the direct drive PTO offered for the PRM500 and PRM750 provides rotation opposite to the engine.

Important Note – PRM1000/1500/1750 ONLY – PTO Retrofit

- A soft shift valve is fitted as standard. When retro-fitting a clutch PTO this valve block assembly **MUST** be changed using the replacement valve block supplied with the PTO kit.

- All hydraulic circuits driven by PRM Newage Ltd PTOs must be designed, installed and maintained in accordance with the hydraulic equipment manufacturer's recommendations and be properly safeguarded against overloading.

Angle Drives – PRM750A/1000A

The angle drive assembly mounts on the front of the gearbox and provides a down angle on the output shaft of 8° on the PRM750, and of 10° on the PRM1000. It also reduces the centreline distance between the engine crankshaft and the gearbox output shaft.

Note: If an angle drive is retro-fitted, the gearbox output rotation will be reversed, it will therefore be necessary to reverse the control lever movements to give the correct output rotation for 'ahead' or 'astern' (see page 8). The oil capacity also increases (see chart, page 6) and a replacement dipstick will have to be fitted. (See reference to pump position below).

In-line – PRM260C/750C

A factory fitted 'step-up' gearbox fitted to the main gearcase brings the output shaft on to the same centreline as the input shaft and reproduces the input shaft length and spline, the adaptor flange and the mounting pads used on certain competitors in-line gearboxes. For oil pump mounting positions, operating lever movements and output rotations (see pages 7 and 8).

Trolling Valve – PRM260,280,500,750,1000,1500,1750

A separate instruction leaflet is issued with each trolling valve.

Fault Finding Chart

SYMPTOM	CAUSE	REASON	REASON
No drive ahead or astern	No oil pressure*	Damaged oil pump* Broken input coupling Oil leaks Insufficient oil	Replace oil pump* Replace coupling Check for evidence and rectify Check level, top up as necessary
Propeller speed does not increase with engine speed, ahead and astern	Low oil pressure to both clutches*	Damaged oil pump* Remote control cable or linkage not allowing F-N-R lever to move correct distance Pressure relief valve spring defective*	Replace oil pump* Remove cable and operate lever by hand to check movement. Adjust cable if necessary Remove valve block and replace spring*
Propeller speed does not increase with engine speed in one direction only	Low oil pressure to one clutch*	Piston rings or feeder worn* Blocked oil strainer* Damaged 'O' ring in hydraulic circuit* Blocked hydraulic passage in valve block* Damaged clutch plates or clutch cones (PRM60/90/125)	Remove appropriate clutch shaft and replace worn feeder or piston rings* Remove, clean and replace if necessary* Check 'O' rings in feeder connectors and piston; replace if necessary* Remove valve block, examine and clean* Remove and examine clutch/clutch cone on appropriate shaft and replace if necessary

SYMPTOM	CAUSE	REASON	REASON
Excessive noise from gearbox at low speeds	Engine idle speed set too low Torsional vibration	Faulty adjustment Torsional incompatibility of elements in driveline	Increase idling speed If not cured by increasing engine idling speed, refer to engine supplier
Excessive noise throughout operating range	Defective input coupling operating range Propeller shaft misalignment	Input coupling worn or damaged Hull flexing or faulty installation	Remove, examine and replace if necessary Check the alignment of the propeller shaft coupling; if necessary rectify by adjusting the shims under the engine mounts or the engine mounts themselves
Excessive vibration throughout operating range	Propeller out of balance Engine/gearbox misalignment Defective bearing	Propeller damaged or badly machined Faulty installation Bearing worn or damaged	Remove the propeller and check that the pitch, weight, diameter and balance of all the blades are equal and rectify if necessary Remove the transmission and check that the flywheel face is flat and that the flexible input coupling is aligned correctly Isolate defective bearing, remove and replace
Excessive oil temperature	Fault in cooling system* Power too high	Defective oil cooler* Oil cooler too small* Defective pressure relief valve* System blocked* Oil pipes too small* Incorrect engine rating	Replace oil cooler* Fit larger capacity cooler* Remove and examine relief valve and replace of necessary* Check and flush out oil cooler and hoses* Fit larger diameter hoses* Re-assess engine power
Oil level needs constant topping up	Oil leaks	Defective oil seal, sealant or 'O' ring Defective oil cooler or hoses*	Clean the outside of the gearcase, particularly around the ends of shafts including the output shaft. Run the engine and inspect the gearbox for leaks. Replace seals as required Check for traces of water in the gearbox oil or oil in the cooling water system. Replace cooler or hoses as necessary
Escape of high pressure from gearbox when dipstick is removed	Defective breather causing leaks past oil seals		Contact distributor or factory for advice
Difficulty in moving single lever control	Faulty installation	Remote control operating cable kinked or frayed	Check the installation and eliminate all tight bends in the cable

* does not apply to PRM60/90/125



Important:

Warning: The above operations should be carried out by suitably qualified personnel and strictly in accordance with the procedures detailed in the workshop manual. Before carrying out any service work always ensure that the engine is switched off and disconnect the operating cable from the gearbox.

Distributor Network

ALBANIA

Motomariner Ltd
Milutin Barac 19
51000 Rijeka
Tel: +385 (0) 51 685-444
Fax: +385 (0) 51 685-433
Email: motomariner@motomariner.hr
Web: www.motomariner.hr

AUSTRALIA

Marine Transmissions Australia
6 Baldry Street
Brighton
Brisbane
Queensland 4017
Australia
Tel: +61 (0)73 869 3242
Fax: +61 (0)40 819 4131
Email: wjordan@bytesite.com.au
Web: http://www.marinetransmissions.com.au/

BELGIUM & LUXEMBOURG

Dintra Transmissies VOF
Keizerswoert 30
3881 Le Putten
Netherlands
Tel: +31 (0)3413 53712/57308
Fax: +31 (0)3413 60046
Email: info@dindra.nl
Web: www.dindra.nl

BOSNIA AND HERZEGOVINA

Motomariner Ltd
Milutin Barac 19
51000 Rijeka
Tel: +385 (0) 51 685-444
Fax: +385 (0) 51 685-433
Email: motomariner@motomariner.hr
Web: www.motomariner.hr

BULGARIA

Genesis Industrial Ltd
39 Morska Sirena Str.
9002 Varna, Bulgaria
Tel: +359 52 610234
Fax: +359 52 610234

CANADA

Marindustrial Ontario Inc
2320 Bristol Circle
Unit 8 Oakville
Ontario L6H 5S3
Tel: 905 829-3004
Email: info-ontario@marind.ca
Web: www.marind.ca

Marindustrial Inc.
80, Harrisville Blvd. Unit
Moncton
NB E1H3N4
Tel: 506 852-3332
Fax: 506 857-8484
Email: info-atlantic@marind.ca
Web: www.marind.ca

Marindustrial (div. Nadco)
8550, Delmeade
Montreal
QC H4T1L7
Tel: 514 342-2748
Fax: 514 342-6151
Email: info-quebec@marind.ca
Web: www.marind.ca

Frontier Power Products Ltd
7983 Progress Way
Delta
BC V4G1A3
Toll Free: 1-877-946-5531
Tel: 604 946-5531
Fax: 604 946-8524
Email: sales@frontierpower.com
Web: www.frontierpower.com

CHANNEL ISLANDS

Herm Seaway Marine
Castle Emplacement
St. Peter Port
Guernsey GY1 1AU
Tel: +44 (0) 1481 726829
Fax: +44 (0) 1481 714011
Email: hermsea@gtonline.net

CHILE

Distribuidora Perkins Chilena S.A.C.
Av. Colorado No 641
Santiago
Tel: +56 (0)2 620 3700
Fax: +56 (0)2 739 1818
Email: diperk@diperk.cl
Web: www.diperk.cl

CROATIA

Motomariner Ltd
Milutin Barac 19
51000 Rijeka
Tel: +385 (0) 51 685-444
Fax: +385 (0) 51 685-433
Email: motomariner@motomariner.hr
Web: www.motomariner.hr

CYPRUS

Char. Pilakoutas Ltd.
P.O. Box 1168
7 Larnaca Road
Nicosia
Tel: +357 (0)2 34912/349572
Fax: +357 (0)2 430294
Email: matheos@pilakoutasgroup.com.cy
Web: www.pilakoutas-industrial.com

DENMARK

BU Power Systems Denmark ApS
Ove Gjeddes Vej 23
5220 Odense SOE
Phone Number: +65 560 560

Bladt Diesel
Bygmarken 7
6230 Rodekro
Tel: +45 40 31 82 41
Email: info@bladdtdiesel.dk
Web: www.bladdtdiesel.dk

EGYPT

Ramco For Engineering And Marine Supply
148 Semouha Garden City
Alexandria
Tel: +20 (0)3 4253155
Fax: +20 (0)3 4253033
Email: ramcomarine@hotmail.com

ENGLAND

A.R. Peachment
Riverside Estate
Brundall
Norwich NR13 5PL
Tel: 01603 714077
Fax: 01603 712211
Email: sales@peachment.co.uk
Web: www.peachment.co.uk
A.S.A.P. Supplies Ltd
Reed House
8b Ellough Industrial Estate
Beccles
Suffolk NR34 7TD
Tel (UK) 0845 1300 870
Tel (International): +44 (0) 1502 716993
Fax: 0800 316 2727
Email: prm@asap-supplies.com
Web: www.asap-supplies.com

Calcutt Boats

Tomlow Road
Stockton
Southam CV47 8HX
Tel: 01926 813 757
Fax: 01926 814 091
Email: boats@calcuttboats.com
Web: www.calcuttboats.com

Engines Plus

Unit F
The Aquarius Centre, Edison Cl
Quedgley
Gloucestershire GL2 2FN
Tel: 01452 729707
Fax: 01452 725194
Email: sales@enginesplus.co.uk
Web: www.enginesplus.co.uk

Golden Arrow Marine

Unit 17 Shamrock Quay
William Street
Southampton SO14 5QH
Tel: 023 8071 0371
Fax: 023 8071 0671
Email: sales@goldenarrow.co.uk
Web: www.goldenarrow.co.uk

Lancing Marine
51 Victoria Road
Portslade
Sussex BN4 1XP
Tel: 01273 410025 / 411765
Fax: 01273 430290
Email: mark@lancingmarine.com
Web: www.lancingmarine.com

Marinemart
Century Park Industrial Estate
Ballin Road
Nuneaton
Warwickshire CV10 9GA
Tel: 024 7639 0111
Fax: 024 7639 0110

Mermaid Marine
14 - 17 The Mews
West Quay Road
Poole
Dorest BH15 1JD
Tel: 01202 677776
Fax: 01202 677777
Email: engines@mermaid-marine.co.uk
Web: www.mermaid-marine.co.uk

FAROE ISLANDS

KJ Hydraulik
Fagralid 1
FO-530 Fuglafjordur
Faroe Islands
Tel: +298 40 70 00
Fax: +298 40 70 01
Email: viggjo@kj.fo
Web: www.kj.fo

FINLAND

Mepratuote Oy
Kaviokuja 8
FIN-20380 Turku
Tel: +358 (0)2 2750 111
Fax: +358 (0)2 2750 120
Email: info@mepratuote.fi
Web: www.mepratuote.fi

FRANCE

I.D.S.
Rue des Chantiers Crucy
44100 Nantes
Tel: +33 2 40 95 95 30
Fax: +33 2 40 95 95 34
Email: sramadour@sa-ids.fr

GERMANY

Dintra Transmissies VOF
Keizerswoert 30
Netherlands
Tel: +31 (0)3413 53712/57308
Fax: +31 (0)341 360046
Email: info@dindra.nl
Web: www.dindra.nl

GREECE

Lelis Diesel Marine
15 Retsina Street
Pireus
Tel: +30 210 41 27 754
Fax: +30 210 41 10 166
Email: info@lelisdieselmachine.com
Web: www.lelisdieselmachine.com

ICELAND

GO - ON ehf
Reykjavikurvegur 68
IS-220 Hafnarfjörður
Tel: +354 566 6200
Fax: +354 566 6262
Email: goon@goon.is
Web: www.goon.is

INDIA

Vinayak Ventures
81, Defence Officers Colony
Ekkatuthangal
Chennai
India - 600 032
Tel/Fax: +91 (0)44 22326679
Tel/Fax: +91 (0)44 22336325
Email: vinayakv1@dataone.in

Lourenco Marine
S20, First Phase
Verna Industrial Estate
Verna
Salcette
Goa - 403 722
Tel: +91 832 2887357
Tel: +91 832 6480302
Fax: +91 832 2887358
Email: sales@lourencomarine.com
Web: www.lourencomarine.com

AVTEC Limited
Punapalli Village
Hosur 635114
Tamil Nadu
Tel: +91 4344 405242
Email: coporate@avtec.in

INDONESIA

Marunda Utama Engineering Pte. Ltd.
17 Kaki Bukit Industrial Terrace
Singapore 416098
Tel: +65 6749 6888
Fax: +65 6749 2198
Email: marunda@singnet.com.sg
Web: www.marunda.com.sg

ITALY

Scandiesel S.r.l.
Via Possessione, 25
28100 - NOVARA
Italy
Tel: +39 348 221 3126
Fax: +39 0321 637227
Email: a.origo@scandiesel.it

Web: www.marinettechnologies.it

LATVIA

Varmaa SIA
Zemturi
Kekavas novads
LV-2111, Latvia
Tel: 00371 67 409500
Fax: 00371 67 409506
Email: info@varmaa.lv
Web: www.varmaa.lv

MALDIVES

Marketech Maldives Pvt. Ltd.
M. Iramaa
1st Floor, Fareedhee Magu
Male
Maldives
Tel: +960 333 1911
Fax: +960 332 0471
Email: info@marketechmaldives.com
Web: www.marketechmaldives.com

MALTA

Leonard Bugeja
29 Main Street
Rabat RBT1015
Tel: +365 2145 4120
Fax: +365 2145 0302
Email: leobugeja@hotmail.com

MONTENEGRO

Motomariner Ltd
Milutin Barac 19
51000 Rijeka
Tel: +385 (0) 51 685-444
Fax: +385 (0) 51 685-433
Email: motomariner@motomariner.hr
Web: www.motomariner.hr

NETHERLANDS

Dintra Transmissies VOF
Keizerswoert 30
3881 LE
Putten
Tel: +31 (0) 341 353712 / 357308
Fax: +31 (0) 341 360046
Email: info@dindra.nl
Web: www.dindra.nl

NEW ZEALAND

Moon Engines Ltd
606 Rosebank Rd
Avondale
Auckland
New Zealand 1026
Tel: +64 (0)9 828 3524
Email: info@prmmarinetransmissionsaustralasia.com
Web: www.prrmmarinetransmissionsaustralasia.com

NORWAY

Møre Båtservice AS
Garverigt. 10
6507 Kristiansund
Tel: +47 (0)71587730
Fax: +47 (0)71587739
Email: post@baatservice.com
Web: www.baatservice.com

PORTUGAL

Motope
Rua da Vitoria 88-3
Apartado 2565
1114-801 Lisbon
Tel: +351 (0)213 427 195
Fax: +351 (0)213 471 840
Email: jsantos@motope.pt
Web: www.motope.pt

POLAND

Techbud Sp. z o.o.
ul. Gorzowska 12
65-127 Zielona Góra
Tel: +48 (0)68 470 72 62
Fax: +48 (0)68 470 72 51
Email: sebastian.mrowcznski@techbud.eu
Web: www.techbud.eu

REPUBLIC OF IRELAND

T.M. Marine
Bunninassa Dromod P.O.
Carrick-On-Shannon
Co. Leitrim
Tel: +353 (0) 371963 8041
Fax: +353 (0) 371963 8550
Email: tmmarine@eircom.net

Charles Featherstone
Avalon
4 Greenhill Road
Wicklow Town
Co. Wicklow
Tel/Fax: +353 (0) 404 61516
Email: charlesfeatherstone@gmail.com

RUSSIA

Perpetuum Mobile Ltd.
125 445 Russia, Moscow
Ul. Smolnaya 24A
Tel: +7 495 967 3307
Fax: +7 495 967 3308
Email: generator@generator.ru
Web: www.generator.ru

SCOTLAND

DDZ Marine Ltd.
Largs Yacht Haven
Irvine Road
Largs KA30 8EZ
Tel: 01475 686072
Fax: 01475 672887
Email: sales@ddzmarine.com
Web: www.ddzmarine.com
Ecodrive Transmissions Limited
Unit 3A, 2 Burntbroom Court
Queenslie Industrial Estate
Glasgow G33 4DZ
Tel: 0141 774 0808
Fax: 0141 774 3999
Web: www.ecodrive.co.uk

SERBIA

Motomariner Ltd
Milutin Barac 19
51000 Rijeka
Tel: +385 (0)51 685-444
Fax: +385 (0)51 685-433
Email: motomariner@motomariner.hr
Web: www.motomariner.hr

SINGAPORE

Marunda Utama Engineering Pte. Ltd.
17 Kaki Bukit Industrial Terrace
Singapore 416098
Tel: +65 6749 6888
Fax: +65 6749 2198
Email: marunda@singnet.com.sg
Web: www.marunda.com.sg

SOUTH AFRICA

Power Torque (Pty) Ltd
773 5th Street
Wynberg, Sandton
P.O. Box 448
Bergvlei 2012
Tel: +27 (0)11 786 4247/9
Fax: +27 (0)11 440 1547
Email: info@powertorque.co.za
Web: www.powertorque.co.za

SPAIN

Clamp España S.L.
Calle Morales 10, Bajo
28410 Manzanares el Real (Madrid)
Tel: +34 91 853 03 48
Fax: +34 91 853 99 11
Email: noelsans@clamp.es
Web: www.clamp.es

SWEDEN

Dintra AB
Norra Sanna 401
655 91 Karlstad
Tel: +46 (0) 545 278 282
Fax: +46 (0) 73050 56 04
Email: info@dintra.se
Web: www.dintra.se

SWITZERLAND (DEALER)

M.Knoepfli
Wiesackerstrasse 128
CH 8105 Regensdorf ZH
Tel: +41 (0)44 840 6221 (sales)
Tel: +41 (0)44 840 6214 (technical)
Tel: +41 (0)44 840 6213 (workshop)
Email: info@m-knoepfli.com
Web: www.m-knoepfli.com

TURKEY

Kadek
1580/2 Sokak 4/A
Mersinli
Izmir
Tel: +90 (0)232 461 27 32
Tel: +90 (0)232 461 68 61
Fax: +90 (0)232 435 35 59
Email: info@kadek.com.tr
Web: www.kadecticaret.com

U.A.E.

Teignbridge Propulsion Gulf, LLC
Warehouse 122
Gate No. 2
Al Jadaf Ship Dockyard
P.O. Box 17065
Dubai
Tel: +971 4 3240084
Fax: +971 4 3240153
Email: teignpro@emirates.net.ae

USA

Atlantis Marine Gear Supply Inc.
418 Boston St.
Topsfield
Massachusetts 01983
Tel: +1 978 887-0001
Fax: +1 978 887-5599
Email: sales@amgs.com
Web: www.marinetransmissions.com

Transmissions Marine Inc.

223 Southwest 33 Court
P.O. Box 21086
FT. Lauderdale
FL. 33335-1086
Tel: +1 954 467-1540
Fax: +1 954 467 1525
Email: sales@marinegears.com
Web: www.marinegears.com

ZIMBABWE

Triple Solutions
46 Cresta Road
Southerton
Harare
Tel: +263 (0) 429074 13
Email: customer.services@triplesolutionsltd.com
Web: www.triplesolutionsltd.com

Maintenance Record

Record your gearbox details here:

Oil Changed

DATE	DATE	DATE	DATE	DATE

MODEL NUMBER

SERIAL NUMBER

RATIO

DATE OF PURCHASE

FIRST OPERATED

DISTRIBUTOR/WHERE PURCHASED

Service Record

DATE	Service Carried Out

Warranty:- PRM Newage Ltd warrants to engine manufacturers and to PRM Newage Ltd distributors that all PRM marine gearboxes manufactured by PRM Newage Ltd will be free from defects in material and workmanship under normal use and service for the period as follows:-

Twenty four months from date of despatch from PRM Newage Ltd.

This warranty does not apply to any gearbox or part that has been subject to misuse, negligence, damage, improper maintenance, incorrect storage or use beyond rated capacity.

Notes

PRM Newage Ltd, Barlow Road, Coventry, CV2 2LD, England

T: +44 (0)24 7661 7141 | F: +44 (0)24 7661 1845 | E: mail@prm-newage.com | W: www.prm-newage.com

